



L2 Where does relay switch connect to?

- 0.25W resistor
- 0.5W resistor
- Generic resistor (used for milli-Ohm shunts in this schematic)

NOTE: Original shows only 4 pins

enable/override all indicators