



MASSE-CODES UND POSITIONEN/EARTH CODES AND LOCATIONS	
G-1002	BATTERIE KANISSE BATTERY SUPPORT
G-1017	MULTER LENKSPULLE (Haupt Masse) BRAKET STEERING COLUMN SUPPORT (MAIN EARTH)
FOLTBELLEN-CODES UND POSITIONEN/SOLDERED-JOINT CODES AND LOCATIONS	
S-1001	IN 14401: NAHE BATTERIE IN 14401: NEAR BATTERY
S-1003	IN 14401: NAHE BATTERIE IN 14401: NEAR BATTERY
S-1006	IN 14401: NAHE ABGANG BOX IN 14401: NEAR BOX
S-1009	IN 14401: NAHE ABGANG ZUENDSCHLOSS IN 14401: NEAR IGNITION SWITCH
S-1013	IN 14401: NAHE ABGANG BOX IN 14401: NEAR BOX
S-1015	IN 14401: NAHE ABGANG BOX IN 14401: NEAR BOX
S-1022	IN 14401: NAHE ABGANG ZUENDSCHLOSS IN 14401: NEAR IGNITION SWITCH
S-1053	IN 14401: NAHE ABGANG BOX IN 14401: NEAR BOX
S-1076	IN 14401: NAHE ABGANG BOX IN 14401: NEAR BOX

SIERRA '92		EINSPISSE-SYSTEM	POWER DISTRIBUTION
PLAN/DIAGRAM 2	AUSGABE/EDITION 8/91	EO 140 2002 000 K 92 BG 14400 AA	